

Trolmaster DCC-1 Installation

The DCC-1 allows users to use a DS type plug-in style module, and the DCC-1 to have two conditions / variables controlled from a single device DS module. Follow the steps below to install your DCC.

DCC-1 / Dual Condition Controller

In some circumstances, it is necessary to have a single device turned on (or off) when a second control condition is activated. There are many examples of this but the most common are:

- Turn on an exhaust fan at night (or day) to reduce CO2, temp or humidity.
- Turn on an exhaust fan at night using a recycling timer OR when Humidity is too high
OR
- Shut off a CO2 device when an exhaust fan is running
- Shut off lights if the temperature gets too warm within the area

The DCC-1 is designed to be used in combination with one of TrolMaster's plug-in style modules... the DSC-1, DSH-1&2, DST-1&2 and the DSP-1.

Once the DCC-1 is connected to the plug-in DS module using a RJ12 cable, the DCC-1 will act in concert with that DS module to control whatever device is connected to the DS module.

To install the DCC-1...

- 1) First you will plug the DS module into a power source near the equipment that will be controlled by the DS module.
- 2) Connect a RJ12 cable from the DS module's communication port to the female port on the DCC-1.
- 3) Plug the DCC-1 into a splitter and RJ cable that is connected back to the Device port on the HCS-1. Note: The DCC-1 gets plugged inline with the DS modules RJ12 cable.
- 4) Next you will select the desired mode on the DCC-1 by using the SET button to select the correct module type, and then pressing the Address button on the DCC-1. The DCC-1 is now connected to the HCS-1 and assigned as the device station you selected on the DCC-1
- 5) Go to the HCS-1 and find the device settings for the DCC-1.
- 6) You can now change the settings for the DCC-1 module.
- 7) If you have not already addressed the DS module that the DCC-1 is connect to, press the addressing button to address the DS module.
- 8) Got to the HCS-1 and enter the settings for the DS module.
- 9) The last thing to do is to decide whether or not to activate the interlock function or not.

The DCC-1 can be set to work in two distinct ways using the Interlock function.

Interlock ON: When the DCC-1 Interlock is selected to be on, BOTH conditions that are associated with the pair of modules that are being used together must be activated TOGETHER in order for the device to be activated.

Interlock OFF: When the DCC-1 interlock is set to be off, EITHER conditions that are associated with the pair of modules can INDIVIDUALLY activate the DS module.

To select the Interlock mode simple press and hold the Interlock button for 3 seconds to toggle between interlock on and off.

Thanks for watching Trolmaster's video on the DCC-1.